

Knomentous / Knomentous Field Data Entry System

Novinium Masters, Service Partners and Licensees enter data in an offline version (Field Data Entry) and sync the data to Knomentous when they have an internet connection. This is done at least daily.

Home

The Home or Landing page lists all Segments for selected customer and purchase order. Purchase order selection can be changed to include all Purchase Orders.

Work order is defaulted to view Open Work Orders. Selection can be changed to view all or just completed work orders.

Click on any segment to drill into segment/subsegment details.

Help

Hover over any segment or subsegment field label to view to see context sensitive help.

Navigation

Use menu bar or bread crumbs to navigate. "Bread crumbs" refers to the blue text directly below the menu above the yellow dotted line. The black text under the dotted line is informational only.

Search

All screens with data grids have search functionality. Use magnifying glass on bottom left corner of screen to search any field in grid.

Segment

Segment record contains information on Team Leader, length of cable, Loop, Pclass and detailed termination numbers and addresses. Each segment has at least one subsegment. If applicable, the following tabs will display: splice locations, associated files, warranty waiver, failure information.

Subsegment

Subsegment contains detailed cable information, flow test, detailed injection information, comments and segment related charges.

Labor Charges

Labor charges are charges made at the work order level, as they are not easily divided or charged at the subsegment level. For example, Delay charges, Daily equipment charges, etc. Click to view invoiced or un-invoiced labor charges per purchase order and work order.

Reporting

See list of reports and their descriptions associated with your user role.